



Excellence made to order.



6800 East 163rd Street
Belton, MO 64012-5463
816-318-8000
1-800-827-3692
FAX 816-318-8100

DuroPatch™

INSTALLATION INSTRUCTIONS

FM-7.5-41
Rev B
6/27/03

DuroPatch™ for Bulkhead Skin Repair

The surface surrounding the damage must be thoroughly wiped down with the supplied isopropyl alcohol wipes to remove dirt, grease, and grime. (If the supplied wipes are not used, a 50% water/50% isopropyl alcohol solution may be used.) Measure out how much DuroPatch™ is required to fully cover the damaged area with a minimum of a 1" border and cut to the desired size and shape with a pair of scissors. Peel off the paper backing from the DuroPatch™ material and place on area needing repair. Firm pressure must then be applied to ensure a good bond. This is most easily accomplished with a roller. The bulkhead is then immediately ready to go back into service!

If you have any problems or for warranty information, please call R•O•M Corporation at 1-800-827-3692 or visit our website www.romcorp.com

Copyright © 2002 R•O•M Corporation. All Rights Reserved. These drawings and the information contained herein are the confidential and proprietary intellectual property of R•O•M Corporation and should not be disclosed to any third party without the express prior written consent of R•O•M Corporation.