



Excellence made to order.

6800 East 163rd Street
Belton, MO 64012-5463
816-318-8000
1-800-827-3692
FAX 816-318-8100



R•O•M Roll-up Shutter

FIELD INSTRUCTIONS FOR A REAR ROLL STRAP

FM-7.5-58
Rev C
02-15-08

1. Cut straps to length needed. This measurement can be taken off the existing strap supplied with your shutter.
2. Next, melt the cut end of the strap with a match or equivalent heat source; this will keep the material from fraying.
3. Make sure the straps are equal length after melting. This is important for equal curtain winding.
4. Approximately 13/16" from the newly cut and melted end, melt a 1/8" hole in the center of the strap.
5. Attach the strap to the operator using a flat washer and pop rivet.
6. Finally, attach the t-clips to the curtain.

If you have any questions or for warranty information, please contact R•O•M Corporation at 1-800-827-3692 or visit our website at www.romcorp.com

Copyright © 2008 R•O•M Corporation. All Rights Reserved. These drawings and the information contained herein are the confidential and proprietary intellectual property of R•O•M Corporation and should not be disclosed to any third party without the express prior written consent of R•O•M Corporation.