

# Roll-up Door - Rear Roll Strap Installation Instructions



**Please read and carefully follow these instructions!**

1. Cut straps to specific length needed.  
This measurement may be taken off the existing strap supplied with your shutter.
2. Melt the cut end of the strap with a match or equivalent heat source.  
This will keep the material from fraying.
3. Be sure the straps are equal length after melting.  
This is important for equal curtain winding.
4. Approximately 13/16" from the newly cut and melted end,  
melt a 1/8" hole in the center of the strap.
5. Attach the strap to the operator using a flat washer and pop rivet.
6. Finally, attach the T-clips to the curtain.

**This completes the installation of the Roll-up Door Rear Roll Strap.**

If you have any questions or problems, please contact your Customer Development Representative at 800-827-3692 ext. 5000.

*These drawings & the information contained herein are the confidential & proprietary intellectual property of Safe Fleet and should not be disclosed to any third party without the express prior written consent Safe Fleet.*