

MHS Roll-up Door Cable Balance Reel Tension Adjustment



Please read and carefully follow these instructions!

Adjustment of Spring Tension on Cable Balance Reels on R•O•M MHS Roll-up Door

Final adjustment, if necessary, can easily be made in your shop or in the field.

To adjust tension (for cable balance reels only):

- a. Use a "C" clamp on housing to hold tension.
- b. Insert any appropriate tool in hole of axle and hold.
- c. Remove the large cotter pin from the other end of the axle.
- d. Turn the axle clockwise for less tension.
Turn the axle counterclockwise. (note: more than 1/2 to 1 full turn) for more tension.
- e. Replace the cotter pin.

If you have any questions or problems, please contact your Customer Development Representative at 800-827-3692 ext. 5000.

These drawings & the information contained herein are the confidential & proprietary intellectual property of Safe Fleet and should not be disclosed to any third party without the express prior written consent Safe Fleet.